




ADAPTOR FOR VESPA TOP V

USUER MANUAL



LIST OF THE COMPONENTS

01		02	
03		04	
05		06	
07		08	
09		10	

Ref.	Description	Quantity
01	ARCH COMPLETE WITH PADS	N.1
02	BASE OF THE ADAPTOR	N.1
03	HIGH ACCESSORY	N.2
04	LOW ACCESSORY	N.2
05	PARTIAL EXAGONAL HEAD SCREW 12x75	N.2
06	NUT ATB M12	N.1
07	NUT M12	N.1
08	WASHER 14x28	N.2
09	EXAGONAL HEAD SCREW 10x25	N.2
10	NUT ATB M10	N.2

Open the bubble wrap package and check that all the parts are present.

Put the arch (01) on the base of the adaptor (02) matching the holes on the brackets of the base of the adaptor with the studs situated at the ends of the arch

Fix the arch to the base of the adaptor on the side with the round hole using the screw (05), the two washers (08) and the self-locking nut (06)

The other side of the arch remains free for the moment. It will be necessary to fix it at the base of the adaptor (side with slotted hole) using the second screw (05) and the nut (07) ONLY when the vehicle is loaded on the adaptor and it will have to be closed before lowering the pad and tightening firmly the vehicle in the adaptor.

Choose the most suitable pair of accessories to lift your vehicle: high accessories (03) or low accessories (04). For the old classic models of Vespa the accessories will be fixed on the inner holes. For the PX the accessories will be fixed on the outermost holes.

Fix the chosen pair of accessories on the base of the adaptor using the screw (09) and their nuts (10)

REMEMBER THAT ONLY ONE PAIR OF ACCESSORIES MUST BE USED

YOU MUSN'T USE SIMULTANEOUSLY BOTH PAIR OF ACCESSORIES.

Now the adaptor is ready to be inserted in the lifter and to be used.

OMCROP SRL
VIA GLERA N. 24
24020 VILLA DI SERIO (BG) - ITALY
TEL.+39 035.663759,
FAX +39 035.6590880
www.omcrop.it
info@omcrop.it